

# Donning procedure Dräger SPC 4400 CLF



1



Perform a visual inspection of the chemical protective suit. Do not use a damaged chemical protective suit!

Open the protective suit and prepare it for entry.

2



Step into the suit through the open zipper before putting on the protective boots/shoes, first into the right and then into the left leg.

3



Once you have put on the boots, pull the cuffs down over the boots.

4



A second person shall connect the boot to the leg of the suit with a chemical resistant adhesive tape.

5



Don the mask and do seal check.

6



If required you can use cotton gloves.

7



Put on the (foil) gloves.

8



Pull the thumb loop over your thumb from the glove.

9



A second person shall connect the (foil) glove to the sleeve of the suit with a chemical-resistant adhesive tape.

10



When wearing foil gloves, over gloves shall be taken to provide additional mechanical protection.

11



A second person shall connect the over glove to the sleeve of the suit with a chemical resistant adhesive tape.

12



Pull the hood over the head and over the full face mask.

13



A second person shall close the zipper and the flap. Make sure that the hook-and-loop fastener is completely flat and that there are no air pockets or unsealed areas.

14



A second person shall close the chin flap. Place one strip on the other strip.

15



A second person shall tape the mask to the suit with a chemical-resistant adhesive tape.

16



Depending on the application attach a filter / compressed air breathing apparatus / PAPR and/or connect an external breathing air supply.

\*Before using this product, carefully read these instructions for use and those of the associated products.

\*\*Attention: When taping with chemical-resistant adhesive tape, wrinkles due to possible leaks must be avoided! Internal regulations must be strictly observed.