

Anlegevorgang Gasdichter Chemikalienschutzanzug Typ 1b



Vorabestellung des Klettbandes auf Haubeninnenseite entsprechend dem Kopfumfang des Anwenders. Bei fest integrierter Vollmaske die Befähigung weit stellen.



Auf die richtige Positionierung der Hosenträger beim Einsteigen achten.



Ohne Schuhe durch den geöffneten Reißverschluss zuerst in das rechte Hosenbein samt Stiefel einsteigen. Anschließend analog in das linke Hosenbein.



Schutzanzug bis zur Taille hochziehen, ggf. Hosenträger anlegen und entsprechende Länge einstellen.



Mit dem linken Arm in den linken Ärmel und Handschuh schlüpfen. Bei Bedarf kann ein Baumwollhandschuh als Unterhandschuh getragen werden.



Danach analog mit dem rechten Arm in den rechten Ärmel schlüpfen.



Kopfhaube über den Kopf streifen.



Gesichtsmanschette auf dem Gesicht und unterhalb des Kinns positionieren, um einen optimalen Dichtsitz zu erreichen. Darauf achten, dass das Klettband auf der Haubeninnenseite die Gesichtsmanschette nicht ins Gesicht rutschen lässt.



Vollmaske auf der Gesichtsmanschette positionieren. Dabei Falten der Kopfhaube glattstreichen und dann die Befähigung der Maske gleichmäßig nach hinten anziehen. Von einer zweiten Person den Dichtsitz der Maske überprüfen lassen.



Beim Schließen des Reißverschlusses immer in Richtung der Verschlusskette ziehen.



Nur mit dem Daumen oder Mittelfinger in die Öse des Reißverschlusses fassen, um die Kraft beim Schließen besser kontrollieren zu können. Sollte der Reißverschluss stecken bleiben, leicht zurückziehen und noch einmal probieren – sicherstellen, dass er gut geschmiert ist.



Als letzten Schritt die Abdecklasche schließen.



Nun Pressluftatmer anlegen und/oder externe Atemluftversorgung anschließen.

Procedure for Donning Gas-tight Chemical Protective Suit Type 1b



Pre-adjustment of tape inside the hood according to head circumference of the user. With integrated full face mask open the harness up to the handle strap.



Ensure the right positioning of the braces before donning the suit.



Remove shoe, then first step through the opened zipper into the right trouser leg and boot. Repeat for the left leg.



Pull the protective suit up to the waist and, where necessary, don the braces and adjust to required length.



Place your left arm into the left sleeve and glove of the suit. If necessary, a cotton glove can be worn as an under glove.



Place your right arm into right sleeve.



Pull the hood over your head.



Position the face cuff around your face and underneath your chin to achieve an optimal seal. Make sure that the tape inside the hood prevents the face cuff from slipping on your face.



Place the full face mask on the face cuff. Straighten out any folds in the hood and adjust the full face mask. Then smoothly pull the harness of the mask to the rear of your head. Have a second person check that the mask is sealed.



Always pull along the line of the zipper when fastening.



Place your thumb or middle finger in the eyelet of the zipper when fastening. This allows you to better control how much power you apply when closing the zipper. If the closing system gets stuck, pull it backwards a little and try again – ensure good lubrication.



Finally, close the cover.



Now don respiratory equipment or connect external breathing air supply.