

# Third-party rescue using the PARAT® 4700/5500/7500

## 1. Opening the PARAT package (depending on package type)

### 1a. PARAT Single Pack



D-84626-2013

Open the carton and pull the inner cardboard box out.



D-84636-2013

Open the inner cardboard box and remove the hood.



D-25165-2015

Hold on to the red tear-away straps and pull on the escape hood until the two filter plugs are pulled out of the filter.



D-84642-2013

The filter openings must be unobstructed in order to breathe freely.

### 1b. PARAT Soft Pack



D-8599-2023

Pull the yellow flap downwards. The security seal breaks automatically.



D-8600-2023

Open the Soft Pack completely so that the front filter sealing plug is removed.



D-8601-2023

Remove the hood from the Soft Pack.



D-8602-2023

The second filter sealing plug is detached from the hood.

### 1c. PARAT Hard Case



D-84550-2013

Open the yellow handle. This breaks the seal at the same time.



D-84560-2013

Open the hard case all the way. The front filter plug is removed automatically and remains firmly attached to the cover.



D-84575-2013

Pull the hood out of the hard case. This also releases the hold-down and the back filter plug is removed automatically.

## 2. Donning the hood



D-25174-2015

Expand the neck seal.



D-25200-2015

Set the opening of the hood against the chin of the person to be rescued.



D-25207-2015

Pull the hood over the head of the person to be rescued.



D-19708-2015

Check for a tight seal and correct the position of the half-mask in the hood if necessary.