

Dräger Cleaning, Disinfection and Maintenance Plan

Cleaning and disinfection in the respiratory protection workshop



What	Manual cleaning	Manual disinfection	Machine cleaning and disinfection
Respiratory protection equipment			
Respiratory protection masks (without communication unit)	Sekusept® Cleaner , concentration 0.5 % to max. 1 % immersion bath; temperature: 20 °C, brush & soft cloth	Incidin® Rapid , concentration 1.5 % immersion bath: 15 min, temperature < 30 °C	<ul style="list-style-type: none"> – Sekumatic® FDR (fluid), Dräger drum washing machine, concentration: 1 %, washing time: 5 min, temperature: 60 °C – Sekumatic® FDR (fluid), in professional dishwashers/washer disinfectors (WD), concentration: 1 %, chemical-thermal disinfection and cleaning time: 5 min, temperature: 60 °C – Eltra® (powder), concentration: 5 g (8.5 ml)/litre, washing time: 20 min, temperature: 60 °C
Lung demand valves	Sekusept® Cleaner , concentration 0.5 % to max. 1 % immersion bath; temperature: 20 °C, brush & soft cloth	Incidin® Rapid , concentration 1.5 % immersion bath: 15 min, temperature < 30 °C	Sekumatic® FDR (fluid), concentration: 1 %, chemical-thermal disinfection and cleaning time: 5 min in dishwasher model Miele G 7856, max. temperature: 60 °C (Important: not suitable for P connectors)
SCBA (basic device)	Sekusept® Cleaner , concentration 0.5 % to max. 1 % immersion bath; temperature: 20 °C, brush & soft cloth	Incidin® Rapid , concentration 1.5 % immersion bath: 15 min, temperature < 30 °C	
Chemical protection suits (reusable)	Sekusept® Cleaner , concentration 0.5 % to max. 1 % immersion bath; temperature: 20 °C, brush & soft cloth	Incidin® Rapid , concentration 1.5 % immersion bath: 15 min, temperature < 30 °C	<ul style="list-style-type: none"> – Sekumatic® FDR (fluid), Dräger washer disinfectant and drying chamber, concentration: 1 %, washing time: 5 min, temperature: 60 °C – Eltra® (powder), Dräger drum washing machine, concentration: 5 g (8.2 ml)/litre, washing time: 20 min, temperature: 60 °C
Equipment, e.g. rubber boots or gloves	Sekusept® Cleaner , concentration 0.5 % to max. 1 % immersion bath; temperature: 20 °C, brush & soft cloth (Important: only wipe Tricotril® gloves on the outside)	Incidin® Rapid , concentration: 1.5 % immersion bath: 15 min, temperature < 30 °C	<ul style="list-style-type: none"> – Sekumatic® FDR (fluid), Dräger washer disinfectant and drying chamber, concentration: 1 %, washing time: 5 min, temperature: 60 °C – Eltra® (powder), Dräger drum washing machine, concentration: 5 g (8.2 ml)/litre, washing time: 20 min, temperature: 60 °C
Workshop equipment			
Work surfaces and test equipment	<ul style="list-style-type: none"> – Incidin® Rapid (for large surfaces) Concentration: 1 %/15 min by wiping – Incidur® Spray (for hard to reach surfaces) Concentration: undiluted/1 min – Incides® N (ready-made cloths) by wiping 	<ul style="list-style-type: none"> – Incidin® Rapid (for large surfaces) Concentration: 1 %/15 min by wiping – Incidur® Spray (for hard to reach surfaces) Concentration: undiluted/1 min – Incides® N (ready-made cloths) by wiping 	not relevant
Work surfaces from stainless steel	Helios® and Chromol®		not relevant
Floors and drying cabinets	Incidin® Rapid (for large surfaces) Concentration: 1 %/15 min by wiping	Incidin® Rapid (for large surfaces) Concentration: 1 %/15 min by wiping	not relevant
Protective clothing			Only for machine cleaning: <ul style="list-style-type: none"> – Turbo Usona® (cleaning detergent) – Triplex® energie plus (detergent booster) – Saprit® protect plus (impregnant)
Personnel hygiene			
Skin and hands	Manisoft® Silonda®, Silonda® lipid	Skinman Soft® 3 ml/30 sec	not relevant
Feet, shoes and socks		Laudamonium® (Athlete's foot prophylaxis)	
Ordering Information			
Ordering Information	Part no.	Ordering Information	Part no.
Manisoft® 24 × 500 ml	79 04 060	Sekusept® Cleaner 1 × 2 litre container	R 62 805
Silonda® 24 × 500 ml	79 04 054	Sekusept® Cleaner 4 × 2 litre container	R 62 063
Silonda® lipid 24 × 500 ml	79 04 055	Incidin® Rapid 1 × 2 litre container	R 62 804
Chromol® 6 × 500 ml	79 04 070	Incidin® Rapid 3 × 2 litre container	R 62 217
Helios® 6 × 500 ml	79 04 069	Incidin® Rapid 6 litre canister	R 61 880
Skinman® soft 24 × 500 ml	79 04 053	Incidur® Spray 12 × 1 litres	79 04 065
Laudamonium® 6 litres	79 04 064	Incides® N 6 containers with 90 cloths	65 70 001
		Incides® N refill pack	65 70 002
			Ordering Information
			R 62 805
			R 62 063
			R 62 804
			R 62 217
			R 61 880
			79 04 065
			65 70 001
			65 70 002
			Sekumatic® FDR 3 × 5 litre canister
			Sekumatic® FDR 20 litre canister
			Eltra® 6 kg drum
			Eltra® 20 kg paper bag
			Saprit® protect plus 20 litres
			Triplex® energie plus 20 kg
			Turbo Usona® 20 litres
			79 04 058
			79 04 059
			R 50 205
			79 04 074
			79 04 068
			79 04 067
			79 04 066

This cleaning, disinfection or maintenance plan is a suggestion which does not release the user from the obligation to verify the validity and completeness. It must be checked and revised continuously.

Please observe the respective, current Instructions for Use and additional manufacturers' documentation, e.g. the Technical Handbook for LDV.

Helios®, Manisoft®, Silonda®, Silonda® lipid, Chromol®, Sekusept® Cleaner, Incidin® Rapid, Incidur® Spray, Incides® N, Skinman® soft, Laudamonium®, Sekumatic® FDR, Eltra®, Saprit® protect plus, Triplex® energie plus and Turbo Usona® are registered trademarks of ECOLAB. Tricotril® is a trademark of KCL GmbH.