

Dräger X-plore® 2100 Reuseable Dust Masks



ST-8869-2005

Preparation and filter attachment



ST-7576-2006

1 Detach the mask cap.



ST-7578-2006

2 Insert the particle filter.

Donning the mask



ST-7610-2006

3 Connect the hooks on the neck strap and place the straps at the back of the neck.



ST-7630-2006

4 Position facepiece over the mouth and nose and position the head cradle on the head.



ST-7620-2006

5 Pull the straps uniformly until the half-mask fits securely and comfortably against your face. If necessary readjust the straps.

Performing seal checks: Before every use!



ST-7641-2006

6 Seal respiratory filter cap with your hands and exhale. The half mask will inflate slightly. If the exhaled air leaks out of the mask, readjust the face-piece and adjust the straps or use a different size. Repeat test until a successful seal check is met.



ST-7661-2006

Ready for use.

Warning: Beards in the sealing area of the mask can cause leaks. Always make sure the mask forms a tight seal and the filter is attached prior to entering a hazardous atmosphere. This poster is not a replacement for reading and understanding the instructions for use for the subject mask and respective filter cartridge, both of which must be read before using either item! Failure to do so could result in sickness or death! For further assistance concerning proper use, ask your supervisor or call your local Dräger organization at +49 451 882-0 or +1 800 922 5518.