

Cylinder specifications

6D

Cylinder 6D

Gas Contents at Full Service Pressure
103 Liters

Service Pressure
1000 psig / 69 bar

Dimensions
13.6" x 3.3" / 346 mm x 83 mm

Weight
3 lb / 1.4 kg

Color
Beige

Primary Uses
LEL mixtures, instrument zero gases (air and nitrogen) oxygen deficiency mixtures, CO mixtures and isobutylene mixtures.

Recommended Equipment
Regulators Model 715, DFR 2001 or Trigger regulators. Connection is 5/8 x 18 thread (not a CGA connection).

Mixture Tolerance
All minor components are certified to +/- 2%.

Warranty
All gases are warranted for 24 months

Meets European Standards
The 6D cylinder with patented „One Fill Valve“ meets European Standards PrEN 12205 requiring that all non-refillable cylinders be fitted with a one way valve to prevent refilling.

