

Regulator Specifications „Trigger“

Regulator

Trigger

Maximum inlet pressure

1000 psig / 70 bar

Maximum outlet pressure

60 psig / 4.1 bar

Inlet Fitting

5/8" x 18

Outlet Fitting

Fits 3/16" / 4.8 mm tubing

Gauge

0-1000 psig / 70 bar

Preset flow rate of 0.5 l/min. with cylinder pressure gauge.

Primary Use

This regulator, also known as "Trigger", is designed to provide aerosol capability. The "Trigger" can be used with 2AL, 8AL and 6D cylinders. Pressing the trigger activates the regulator and dispenses gas at a present flow rate of 0.5 l/min. The trigger can also be locked in the "ON" position for continuous gas flow.

Construction

Body – nickel plated brass

Seat - Teflon[®] and Buna

Seals - Viton[®]

Weight

0.7 lb / 350 g

Warranty

All regulators are warranted for 24 months.



[®] Registered trademark of The Dupont Company