

Revalstraße 1 • 23560 Lübeck

DATUM

07. Dezember 2007

UNSER ZEICHEN

TEL

+49 451 882 1630

FAX

+49 451 882 7 1630

E-MAIL

suzanne.johnson@draeger.com

INTERNET

www.draeger.com

PARAT® C: Exposure Time against H₂S

The exposure time of PARAT® C against H₂S has been officially tested from the independent laboratory BGIA.

Following exposure time of PARAT® C against hydrogen sulphide (H₂S) was confirmed under given conditions:

Exposure time: 120 minutes (which are in conjunction to the DIN 58647-7 standard):

- 1) Measured with a concentration of 2500ppm H₂S
- 2) Under a constant flow of 30 Liters per Minute

Please keep in mind that the exposure time is dependent upon the measured concentration of the H₂S. If higher concentrations of H₂S are present, this will shorten the exposure time.

These conditions apply to the following PARAT® C products:

Dräger PARAT® C single-pack	R 52 817
Dräger PARAT® C soft-pack	R 53 555
Dräger PARAT® C traveller-pack	R 52 818
Dräger PARAT® C box	R 54 461
Dräger PARAT® C twin-pack	R 52 845
Alternative Filter PARAT® C (CO-P2)	67 36 192

Dräger Safety AG & Co. KGaA
Revalstraße 1
D-23560 Lübeck
Tel +49 451 882-0
Fax +49 451 882-2080
www.draeger.com

Sitz der Gesellschaft: Lübeck
Handelsregister:
Amtsgericht Lübeck HRB 4097
UID-Nr. DEB12128834
WEEE-Reg.-Nr. DE13636930

Vorsitzender des Aufsichtsrats:
Dipl.-Ing. (BA) Stefan Dräger
Geschäftsführung:
Dräger Safety Verwaltungs AG
Vorstand:
Prof. Dr.-Ing. Albert Jugel (Vors.)
Thomas Holzgreve

Deutsche Bank AG, Lübeck
Konto-Nr. 030210900
BLZ 230 707 10
Swift-Code DEUTDEHH 222
Commerzbank AG, Lübeck
Konto-Nr. 0146803
BLZ 230 400 22
Swift-Code COBADEFF 230

Dresdner Bank AG, Lübeck
Konto-Nr. 0371072500
BLZ 230 800 40
Swift-Code DRES DE FF 230
HSH Nordbank AG, Kiel
Konto-Nr. 7053002780
BLZ 210 500 00
Swift-Code KILADE 22