

Dräger X-Plore® 2100 Half Masks



ST-8869-2005



ST-1762-2005

Dräger X-plore® 2100 Silicone



ST-1114-2005

Dräger X-plore® 2100 EPDM



ST-398-2003

Particle filter

The Dräger X-plore® 2100 is the reusable alternative to disposable dust masks. The Dräger X-plore® 2100 is the ideal solution for people working frequently in dusty environments. Its replaceable filters provide protection against solid and liquid particles. This half mask offers the perfect combination of comfort, safety and cost-effectiveness.

The Dräger X-plore® 2100 achieves an excellent fit with leakage rates much below those of conventional filtering facepiece respirators (FFRs). The filters with protection levels R95 and P100 are characterized by high filtration efficiency, and low breathing resistance due to a large surface area. This leads to an extended life and overall cost savings.

Donning and doffing the mask as well as filter replacement is quick and easy. The ergonomic non-slip head harness ensures a good fit, while the elastic straps with an integrated neck hook are easy to open and close, and allow precise adjustment of the mask. The mask can also be removed without the need to take off a safety helmet ("drop-down" strap system).

The exhalation valve is positioned at the lowest point to ensure a dry and pleasant atmosphere inside the mask. Its low weight means it is hardly noticeable, making the mask extremely comfortable.

Two high quality materials are available to choose from: EPDM, or comfort-added silicone, which is especially good for sensitive skin. Additionally, the silicone version is available in two sizes – ensuring a secure seal on different face shapes.

The mask can be easily disassembled and reassembled, ensuring hassle-free cleaning. In combination with the low-cost replaceable filters, overall total cost savings can be easily achieved.

The Dräger X-plore® 2100 is used daily in a variety of industries including mining, metal, timber and chemical, renovation and demolition work, as well as agriculture and the building industry.

TECHNICAL DATA

Mask body	Silicone (blue) or EPDM (black)	
Sizes	Dräger X-plore® 2100 Silicone: small/medium (s/m) and medium/large (m/l)	
	Dräger X-plore® 2100 EPDM: universal size	
Filter connector	Plug-in connector for Dräger particle filters of type R95 or P100	
Weight	Approximately 110 g	
Head harness	Flexible textile strap with polypropylene harness, drop-down feature	
NIOSH Approvals	R95	TC-84A-3160
	P100	TC-84A-1129
Spare parts	Available	

ORDERING INFORMATION

Mask		Order No.
Dräger X-plore® 2100, EPDM	Universal size	R 55 881
Dräger X-plore® 2100, Silicone	Medium/large (m/l)	R 55 882
	Small/Medium (s/m)	R 55 883

Filter	Order No.
R95 Replacement filters, pack of 25	67 37 352
P100 Replacement filters, pack of 25	67 36 777

Mask and Filter Kit	Order No.
Dräger X-plore® 2100, EPDM, universal size, with (5) P100 filters	R 55 910
Dräger X-plore® 2100, silicone, size m/l with (5) P100 filters	R 55 915

SUBSIDIARIES

DRAEGER SAFETY, INC.
101 Technology Drive
Pittsburgh, PA 15275-1057
USA
Tel 1-412-787-8383
Fax 1-412-787-2207
www.draeger.com

CUSTOMER SERVICE
Tel 1-800-858-1737
Fax 1-800-922-5519

TECHNICAL SERVICES
Tel 1-888-794-3806
Fax 1-888-794-3807

DRAEGER CANADA LTD.
7555 Danbro Crescent
Mississauga, ON L5N-6P9
Canada
Tel 1-905-821-8988
Fax 1-905-821-2565

CUSTOMER SERVICE
Tel 1-877-372-4371
Fax 1-800-Fax-Tube

DRAEGER SAFETY S.A. DE C.V.
Av. Peñuelas No. 5
Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Queretaro, Qro. C.P. 76148
Mexico
Tel 52-442-246-1113
Fax 52-442-246-1114