

Dräger Panorama Nova Dive diving mask

The Panorama Nova Dive is based on a tried-and-tested mask body. This, together with the 5-point head harness, provides an outstanding seal.



ST-1457-2003

The mask has three Dräger plug-in connections. The central port is designed for connecting the main breathing system. The two side connections may be used for an emergency second stage regulator and a microphone for the communication system. The Panorama Nova Dive features an additional exhalation valve which makes it very easy for the diver to purge water. At the surface the diver can breathe ambient air providing he has not inserted the main breathing system into the mask. This conserves the cylinder air supply until actually needed. As it is positioned close to the face, the new flat visor offers a wide field of vision. This also reduces the volume of air inside the mask, thereby reducing buoyancy. There are two integrated nose pieces in the

visor to permit pressure equalisation. The mechanical residual pressure alarm may be inserted into the side of the visor as an option. The Panorama Nova Dive also comes with a protective visor for welding; this folds down. After a dive the mask can be removed by means of the unique quick release system.

The Panorama Nova Dive has also been developed for use with rebreathers. For this application the inner mask is replaced by an integrated bite mouthpiece. No connector is provided in rebreather masks for the residual pressure alarm.

The Panorama Nova Dive is supplied in a tough mask case.



ST-2671-2004

Panorama Nova Dive



ST-2681-2004

Panorama Nova Dive

TECHNICAL DATA

Full face mask for open-circuit diving apparatus and rebreathers

Convenient pressure compensation system / lever system

Low air volume inside mask

Anti-fogging visor (protective lacquer)

EPDM mask body with 5-point head harness, inc. patented quick release system

Inner mask for open systems or mouthpiece for rebreathers

Integrated relief valve

Three mask connections - main breathing system (regulator or rebreather)

- alternative air supply / Shark regulator

- microphone (communication unit UT 402)

Mask connection for residual pressure alarm only in versions for the following open-circuit systems: Panorama Nova Dive, Panorama Nova Dive for Welding

ORDER INFORMATION

Description	Order-No.
Panorama Nova Dive Sport (without mask case)	T 53 700
Panorama Nova Dive	T 53 510
Panorama Nova Dive R	T 52 730
Panorama Nova Dive SW, inc. protective visor for welding	T 53 525
Panorama Nova Dive NM	T 16 000
Valve mouthpiece for LAR	T 16 010
Valve mouthpiece for Dolphin	T 53 520
Valve mouthpiece for FGT 5400	T 16 418
Valve mouthpiece for SMT 7000	T 16 330

HEADQUARTERS:

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck, Germany

www.draeger.com

SUBSIDIARIES:**AUSTRALIA**

Draeger Safety Pacific Pty. Ltd.
Axxess Corporate Park
Unit 99, 45 Gilby Road
Mt. Waverley. Vic 3149
Tel +61 3 92 65 50 00
Fax +61 3 92 65 50 95

CANADA

Draeger Canada Ltd.
7555 Danbro Crescent
Mississauga,
Ontario L5N 6P9
Tel +1 905 821 89 88
Fax +1 905 821 25 65

P. R. CHINA

Beijing Fortune Draeger
Safety Equipment Co., Ltd.
Yu An Lu A 22, B Area
Beijing Tianzhu Airport
Industrial Zone
Houshayu Shunyi District
Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80-05

FRANCE

Dräger Safety France SAS
3c route de la Fédération,
BP 80141
67025 Strasbourg Cedex 5
Tel +33 3 88 40 59 29
Fax +33 3 88 40 76 67

USA

Draeger Safety, Inc.
101 Technology Drive
Pittsburgh, PA 15275
Tel +1 412 787 83 83
Fax +1 412 787 22 07

MEXICO

Draeger Safety S.A. de C.V.
Av. Peñuelas No. 5
Bodega No. 37
Fraccionamiento Industrial
San Pedrito
Querétaro, Qro México
Tel +52 442 246-1113
Fax +52 442 246-1114

NETHERLANDS

Dräger Safety Nederland B.V.
Edisonstraat 53
2700 AH Zoetermeer
Tel +31 79 344 46 66
Fax +31 79 344 47 90

REP. OF SOUTH AFRICA

Dräger South Africa (Pty) Ltd.
P.O.Box 68601
Bryanston 2021
Tel +27 11 465 99 59
Fax +27 11 465 69 53

SINGAPORE

Draeger Safety Asia Pte. Ltd.
67 Ayer Rajah Crescent # 06 03
139950 Singapore
Tel +65 68 72 92 88
Fax +65 67 73 20 33

SPAIN

Draeger Safety Hispania S.A.
Calle Xaudaró 5
28034 Madrid
Tel +34 91 728 34 00
Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
NE24 4RG
Tel +44 1670 352 891
Fax +44 1670 356 266