



Webinar Summary: Lithium-Ion Battery Safety for First Responders

Dräger

Technology for Life

The webinar provides an in-depth discussion on the importance of lithium-ion batteries, the risks associated with them, and the safety measures required for first responders. It is structured to cover the fundamental aspects of battery safety, followed by specific challenges and mitigation strategies for first responders, presented by Christoph from Dräger.

Importance of Lithium-Ion Batteries

Lithium-ion batteries are crucial for modern energy storage, particularly as the world shifts from conventional fuels to renewable energy sources. They are widely used in mobile devices, electric vehicles, and large-scale energy storage systems. Their ability to store power with high energy densities makes them pivotal in supporting the decarbonization of the planet and balancing renewable energy supplies like solar and wind power.

Understanding the Risks

While lithium-ion batteries are beneficial, they come with significant risks, especially during manufacturing, usage, and in case of malfunctions:

- **Fire and Explosion:** Can be triggered by thermal runaway due to overcharging, physical damage or internal defects.
- **Dust Explosions:** Possible in manufacturing environments.
- **Exposure to Hazardous Chemicals:** Lithium, cobalt, nickel, and toxic gases and vapours liberated in a thermal runaway of batteries pose health risks through inhalation, skin contact, and ingestion.
- **Electrical Shock:** Handling batteries improperly can lead to severe injuries by electrical shock.

Reason for Failures

- **Mechanical Abuse:** Physical damage to batteries can cause leaks of flammable and toxic gases.
- **Thermal Abuse:** Operating batteries outside their design temperature range can lead to premature aging and potential failure.
- **Electrical Abuse:** Overcharging or discharging batteries too quickly can cause thermal runaway, resulting in fires or explosions.
- **Combination of Abuses:** Simultaneous mechanical and electrical abuse can exacerbate risks, leading to more severe incidents.

First Responders' Challenges and Mitigation Tactics

1. Identifying Hazards:

- Recognize signs of thermal runaway, such as dark smoke, white vapor clouds, and hissing noises.
- Use thermal imaging cameras and gas detectors to identify and assess risks accurately.

2. Establishing Safe Parameters:

- Set up safe perimeters to protect against explosion hazards and toxic gas exposures.
- Ensure proper ventilation in confined spaces to prevent gas accumulation.

3. Utilizing Proper Tools and PPE:

- Equip responders with full PPE, including breathing protection and arc flash helmets.
- Be aware of the capabilities and limitations of thermal imaging cameras and gas detectors.

4. Suppression and Cooling:

- Understand the balance between suppressing fires and preventing further gas generation.
- Continuous monitoring for potential re-ignition is essential.

5. Knowledge and Training:

- Stay updated on safety guidelines and standard operating procedures.
- Regular training is crucial for responders to handle incidents effectively.

6. Post-Incident Procedures:

- Follow strict hygiene and cleaning practices to remove toxic residues.
- Manage stranded energy and remaining electrolyte leaks safely.



D-2506-2024

Key Takeaways

- **Risks Awareness:**
Be aware of the new hazards associated with lithium-ion batteries across various sectors, including industrial, domestic, and mobility applications.
- **Vapor Clouds:**
Recognize the dangers of vapor clouds and the potential for explosions.
- **Training and Knowledge:**
Continuous education and training are vital for first responders to stay prepared and safe.

Resources and Further Information

- Dräger Voice Database for protection and detection tools.
- Technical references and guidelines from various organizations such as NFPA, UL, and EV Fire Safe.
- Training programs from the UL Fire Safety and Research Institute.
- Detailed studies on toxic gas emissions and battery safety from institutions like RISE and publications like Batteries Magazine.

This summary highlights the critical points covered in the webinar, emphasizing the importance of understanding the risks associated with lithium-ion batteries and the necessary precautions for first responders.

Imprint:

Dräger Safety AG & Co. KGaA, Revalstraße 1, 23560 Lübeck, Deutschland
www.draeger.com

DMC-112856