



Dräger Prestor 5000

Respiratory Protection Test Equipment

The Prestor 5000 from Dräger is a highly efficient device that tests the integrity and thus safety of full face respiratory masks. The automatic testing program reduces the time needed to inspect each mask, which makes the testing of even a large number of masks fast and convenient.

Highlights

Automatic mask positioning

The pneumatic fastening and tension feature automatically attaches the full-face mask into the optimal position. The functionality of the adjustment harness is examined during the test procedure. A special fixture is also available for the inspection of Dräger masks with helmet adapters.

Natural head shape

The gel face and underlying structure of the head unit is made so as to resemble human skin. This way, the positioning and fitting of the mask is as realistic as possible. Users can change the gel face themselves, when desired.

Realistic in every way

An integrated atomizer ensures that a realistic amount of moisture enters the exhalation valve during testing. This supports the test procedure by simulating the effect of the exhaled air during real-life wear.

Control via PC

Operating the Prestor 5000 and the graphic display of all testing procedures is done using a PC¹. The device is simply connected using a USB cable. Test protocols are auto-matically generated in order to guarantee precise documentation. The whole procedures can also optionally be done using a pedal switch.²

¹ PC is not included

² Pedal switch is not included

Required for operation and included accessories

PC meeting the following hardware and operating system conditions:

- Processor 1.6 GHz or better
- RAM 2 GB or more
- Space on hard disk: min. 500 MB
- Monitor resolution of at least 1,024 x 768 pixels
- Windows® 7, 8 and 10
- USB port

Windows® is a registered trademark of Microsoft Corporation.

Accessories



Barcode scanner

Available in the following versions: wireless, wired, wired/drop resistant and wireless/drop resistant.



Dräger Protector Software 5.0.3



Mask-helmet adapter

Holder to be attached to the test head for all Dräger mask/helmet-combinations.



Workbench mounting

With the proven click closure for a safe mounting at the work bench.

Software



Drägerware.Workshop Software 5000/7000

- Complete solution with high flexibility for workshop management
- Innovative, user-friendly software solution improves processes and increases transparency and efficiency

Connective Products



Dräger FPS 7000

- Comfortable full face mask with different front port options
- Combinable with helmets, communication and respiratory systems
- Available in multiple sizes for a secure fit



Dräger Panorama Nova

- Full face mask protecting the respiratory tract and eyes
- Offers different thread connections: RA (Rd40), PE (M45x3), ESA or P Dräger plug-in connection
- EPDM or silicone mask body, triplex or PC visor

Not all products, features, or services are for sale in all countries. Trademarks mentioned herein are the property of its respective owner. Trademarks may be owned by Drägerwerk AG & Co. KGaA (Dräger) or its affiliates in certain countries and not necessarily in the country in which this material is released. Visit www.draeger.com/trademarks for the current status of Dräger's trademarks.

Dräger Safety AG & Co. KGaA

Revalstraße 1
23560 Lübeck
Germany
Tel: +49 800 882 883 0

Corporate Headquarters

Drägerwerk AG & Co. KGaA

Moislinger Allee 53–55
23558 Lübeck
Germany

