



Dräger FPS® 7000 Head-up Display (HUD) Accessories for Breathing Apparatus

One of the many benefits of the FPS® 7000 Facemask is the option of fitting a head up display. Always within the field of view the head up display allows easy monitoring of the cylinder contents without any manual action by the wearer.

Highlights

Easy to fit and remove

The display fits easily into the FPS 7000 facemask, and can be quickly fitted without the need for tools, saving time during maintenance. In an emergency you can transfer the HUD between facemasks in a matter of seconds.

Well Protected

The HUD is well protected in the facemask and can not be damaged by heat, shocks, humidity or chemicals.

Long battery life

Providing on average 360 hours of use and easily changed without the need for tools.

Wireless operation

The transmitter unit wirelessly transfers data to the facemask, avoiding time consuming connection of cables, reducing costs and connection errors.

Easy to read LED's

Red, amber and green LEDs provide precise information about your cylinders air pressure at all times. The display automatically adapts to ambient brightness enabling clear indication of pressure information , even under poor lighting conditions.

Additional low air pressure warning

In addition to the SCBA's primary low pressure alarm a red LED on the HUD flashes if the cylinder pressure reaches the low pressure warning threshold. This provides the wearer with an additional warning.

Connective Products



Dräger Bodyguard® 1500

- Automatic wireless PASS system alerts team if wearer is motionless or distressed
- Emits clear and distinctive signals and alarms
- Wireless data transmission from the pressure gauge to the PAS device



Dräger FPS 7000

- Comfortable full face mask with different front port options
- Combinable with helmets, communication and respiratory systems
- Available in multiple sizes for a secure fit



Dräger PSS AirBoss

- High-performance self-contained breathing apparatus for firefighting
- Offers best in class ergonomics and is one of the lightest weight breathing apparatus
- Compatible with Dräger FireGround



Dräger PSS® 4000

- Professional self-contained breathing apparatus for firefighting
- Offers comfort, stability, lightweight and advanced harness materials for extended wear

Not all products, features, or services are for sale in all countries. Trademarks mentioned herein are the property of its respective owner. Trademarks may be owned by Drägerwerk AG & Co. KGaA (Dräger) or its affiliates in certain countries and not necessarily in the country in which this material is released. Visit www.draeger.com/trademarks for the current status of Dräger's trademarks.

Dräger South Africa (Pty) Ltd.

Johannesburg: 2 Ruacana Street, Waterfall Commercial District, (cnr Beatty Street), Buccleuch, 2090
Tel: +27(0)11 059 4200

Dräger South Africa (Pty) Ltd.

Durban: 17 Thynk Industrial Park Cnr Brickworks and Queen Nandi Drive, Briardene, Durban North, 7561
Tel: +27(0)31 812 7900

Corporate Headquarters

Drägerwerk AG & Co. KGaA

Moislinger Allee 53-55
23558 Lübeck
Germany

Dräger South Africa (Pty) Ltd.

Cape Town: Unit 2, 7 on London, 7 London Circle, Brackengate Business Park Brackenfell, 7561
Tel: +27(0) 21 819 3000

Dräger Kenya Ltd

Nairobi: 8th Floor Office 2, Sanlam Tower, Westlands
Tel: +25(0) 47 462 40336

