



# Work Wear Safety Helmets

## Veiligheidshelmen

---

For optimal protection of the head, a safety helmet should be adjusted to the size of the head of the user. The usefulness of the helmet duration is determined by, among others, cold, heat, chemicals and (in)correct use. Safety helmets are also available with integral visor or an integrated goggle.

# Belangrijkste eigenschappen

## **EVO2® industrial safety helmet**

EVO2® features a traditional 6-point polyethylene harness and OneTouch™ slip ratchet. The EVO2® offers the most economical top level protection. Conforms to EN397.

## **Safety helmets**

The lightweight comfort helmet has a 6-point polyethylene harness and can easily be adjusted to the size of user's head. Available in different colors.

## **Tough HDPE shell**

In tests the EVO2® proved far tougher than the EN397 standard required and far tougher than any of its competitors.

## **Safety helmet with integral visor**

The helmet with integral visor ensures that eye protection is on hand when needed and never lost. Available in different colors.

## **Harness**

Traditional 6-point polyethylene harness.

## **Safety helmet with integrated goggle**

This safety helmet is made of polyamide, complete with PC safety glasses. The helmet is equipped with comfortable 4-point interior and two knobs for size adjustment. Available in different colors.

## **Chamlon™ sweatband**

Egyptian cotton core with porous PU coating for maximum sweat absorption. PH neutral, dermatologically tested.

## **Service & Support**

Dräger offers 24/7 service and support, including full certification on all Dräger and non-Dräger products. Contact us for more details.

### **3D precision fitting**

Never before has such a precise fit been attainable on an industrial safety helmet, using the unique 1-2-3 point harness depth settings.

### **Adjustment**

OneTouch™ Slip Ratchet.

### **Electrical insulation**

Meets the EN50365 Class 0 10KV standard. This standard is applicable to electrically insulated helmets used for working live or close to live parts on installations not exceeding 1000Vac or 1500Vdc.

### **Universal slots**

Enables firm fitting of a range of Surefit™ safety visors and ear defenders.

### **Optional: Branding**

Extra large area for logos on the front, sides, and rear.

### **Instruction of use**

- fit helmet on head and fasten strap to ensure fit
- for adequate protection this helmet must be worn with peak facing forward
- ensure the helmet is adjusted to the size of the user's head
- after use the helmet may be cleaned with the use of soap and warm water and dried with soft cloth

### **Limitations of use**

Any helmet subjected to severe impact should be replaced immediately. Please check instruction of use from the manufacturer.

Niet alle producten, functies of diensten worden in alle landen verkocht. Hier genoemde handelsmerken zijn het eigendom van hun respectievelijke eigenaar. Handelsmerken kunnen door Drägerwerk AG & Co. KGaA (Dräger) of zijn filialen in bepaalde landen zijn gedeponeerd, en niet noodzakelijkerwijs in het land waarin dit materiaal wordt uitgebracht. Ga naar [www.draeger.com/trademarks](http://www.draeger.com/trademarks) voor de actuele status van de handelsmerken van Dräger.

### **Dräger Marine & Offshore**

Afdeling Verkoop  
Tel: +31 10 2952740

### **Corporate Headquarters**

#### **Drägerwerk AG & Co. KGaA**

Moislinger Allee 53-55  
23558 Lübeck  
Germany

