

Wildland Respiratory Kit

Economical kit: modern design and light weight half mask offers you extra protection and comfort. Wildland Respiratory Kit contains everything you need for long lasting protection under tough conditions.



Wildland Respiratory Kit

Dräger X-plore® 3500



Benefits

Twin-filter half-face mask

The Dräger Wildland Respiratory Kit includes the Dräger X-plore® 3500 half mask, Bayonet filters, cleaning wipes and a case for easy portability. The twin-filter system utilizes the Dräger X-plore® Bayonet filters to ensure effective, long-lasting protection.

Comfortable: easy respiration with low resistance

The innovative design of the respiratory protection mask ensures easy, comfortable breathing. A large opening on the exhalation valve keeps resistance low. The cascade-shaped nose bridge offers optimal distribution of pressure. The material of the masks also makes them comfortable to wear: the X-plore 3500 mask is particularly soft and skin-friendly because it is made of DrägerFlex material. First-class comfort is combined with exceptional durability.

Well-fitting: optimal fit for any face

The positioning of the filters on the sides and the flat design of the masks provide maximum field of view and secure fit, even when worn with a protective visor. The Dräger FlexiFit head straps provide additional comfort. Thanks to the soft materials and ergonomic shape, the mask is a perfect fit for nearly any wearer. Even under a helmet, the head strap is hardly noticeable. Its innovative design makes it easy to don and doff without getting tangled in the wearer's hair. The special mask straps with their criss-cross pattern are simple to adjust, ensuring optimal distribution of weight and pressure so the mask is even more comfortable. Plus, there are three sizes to choose from (S, M, L) to make sure the masks are always an optimal fit.

Safe: innovative features ensure optimal safety

Dräger half masks are valued for their precision design which offers optimal protection. For example, the cascade shape of the valve creates an extra powerful seal. The specially designed, flexible nose bridge ensures an extra secure fit that contours perfectly to the face, even when worn with protective eyewear. The Dräger X-plore 3500 are equipped with two bayonet connectors on the sides for combination with the extensive Dräger X-plore bayonet filter series. These also provide a high level of safety: filters are so simple to attach it is practically impossible to mount them incorrectly.

Simple: improved product design for easy handling

The mask is made of only a few parts. The advantage of this is fast easy cleaning. No special training is required, either to use the respiratory protection masks or to (dis)assemble them. The Dräger X-plore 3500 also features a drop-down strap design. Thanks to this, the mask can be removed simply by releasing the fastener at the neck without having to remove the helmet first, for example. When the mask is in the standby position, its inner side remains aligned with the body, protecting it from soiling.

System Components



D-1526-2018

Dräger X-plore® 3500

A perfect combination: modern design and light weight offer you extra protection and comfort. Dräger X-plore® 3500 offers long lasting protection under tough conditions.



D-11919-2016

Allegro Cleaning Pads

Personal safety equipment cleaning pad. Designed for use on respirator face pieces and other personal safety equipment. Contains no alcohol.



D-21883-2020

Dräger X-plore® Bayonet Filters

Experience a new dimension of comfort and safety in respiratory protection: the Dräger X-plore® Twinfilter series. It sets the benchmark in comfort and use. The utilization of modern materials, coupled with an attractive design, guarantees maximum comfort and user acceptance.

Related Products



Dräger X-plore® 5500

The Dräger X-plore® 5500 full face mask is the right solution for environments where not only increased respiratory protection is required, but a clear vision is mandatory.



Dräger X-plore® 2100

Dräger X-plore® 2100 is the reusable alternative to disposable dust masks. An ideal solution for people who frequently work in dusty environments. This half mask offers the perfect combination of comfort, safety and cost-effectiveness.



Dräger X-plore® 2100 Replacement Filters

(EPDM, universal size) + 5 filters P100

Technical Data

Kit Specifications

Dimensions	8.5" x 5.9" x 3.5"
Sizes	Small (S), Medium (M), Large (L)
Weight	Approximately 15.8 oz/ 450 g

X-plore 3500 Specifications

Mask Body	made of DrägerFlex – a durable material that is hypoallergenic
Sizes	Small (S), Medium (M), Large (L)
Weight	Approximately 3.351 oz / 95 g
Approvals	NIOSH approval

Ordering Information

Wildland Respiratory Kit	Large Kit	NA 10754
	Medium Kit	NA 10753
	Small Kit	NA 10752

Not all products, features, or services are for sale in all countries.
Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to www.draeger.com/trademarks to find the current status.

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

USA

Dräger, Inc.
7256 S. Sam Houston Parkway W.,
Suite 100
Houston, TX 77085
1 800 4DRAGER
(1 800 437 2437)

CANADA

Dräger Safety Canada, Ltd.
2425 Skymark Ave., Unit 1
Mississauga, Ontario L4W 4Y6
1 877 DRAGER1
(1 877 372 4371)

Locate your Regional
Sales Representative at:
www.draeger.com/contact

