

Technical Specification

Dräger Wash9

Fully automatic cleaning machine

Made by

Harstra
INSTRUMENTS

With the cleaning machine Wash9 you can clean up to 9 full face masks in an economical and simple way. You can choose one of the 3 washing programs.

After cleaning, you can quickly transfer the removable stainless steel wire basket into a drying cabinet.

- Compact cleaning machine
- Contaminated masks are placed in the stainless steel basket and are cleaned fully automatically
- Stainless steel basket can be removed and transferred to the drying cabinet
- The water temperature in the washing tank is 55° C
- Water pressure: 2-3 bar
- Water consumption: 9 l per wash cycle
- It is recommended to install a water softener if the hardness of the water is more than 4° D.H.



Cleaning machine
(Fig. similar)



water softening system
(Fig. similar)



Stainless steel fine mesh basket
(Fig. similar)

TECHNICAL DATA

Dimensions (H x W x D)	Exterior 850 x 600 x 620 mm Interior 340 x 540 x 480 mm
Weight	68 kg
Tank capacity	23 l
Max. capacity	9 full face masks
Main link	400 Volt AC 50 - 60 Hz
Fresh water supply line	G ¾" up to max. 50° C
Wastewater connection	Drain pipe 29 mm diameter
Washing times	5 minutes 10 minutes 22 minutes

ORDER INFORMATION

Dräger Wash9	69 26 694
--------------	-----------

ACCESSORIES

Water Softening System (WO)
Stainless steel fine mesh basket
Basket with 9/12 compartments

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53-55
23558 Lübeck, Germany
www.draeger.com

Manufacturer

Harstra Instruments B.V.
Giek 11 | 3891 KA Zeewolde |
Nederland
Postbus 186 | 3890 AD Zeewolde |
Nederland

REGION DACH

Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck
Tel +49 451 882 0
Fax +49 451 882 2080
info@draeger.com

REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.
Complejo Business Park
V tower, 10th floor
Tel +507 377 9100
Fax + 507 377 9130
contactcsa@draeger.com

REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd
25 International Business Park
#04-20/21 German Centre
Singapore 609916
Tel +65 6308 9400
Fax +65 6308 9401
asia.pacific@draeger.com