

Dräger FPS® 7000 Head-up Display NFPA-Certified Accessory for SCBAs

One of the many benefits of the FPS® 7000 full-face mask is the head-up display (HUD) required by NFPA 1981. Always within the field of view the head-up display allows easy monitoring of the cylinder contents and battery status without any manual action by the wearer.



Benefits

Easy to fit and remove

The Dräger Head-Up Display (HUD) fits easily into the FPS 7000 facemask - and can be installed or removed without the need for tools, saving time during maintenance. In an emergency, the HUD can be transferred between face masks in a matter of seconds. The HUD connects automatically with the corresponding SCBA – either a Dräger PSS 7000 or PSS 5000.

Well protected

The HUD is well protected in the facemask and can not be damaged by heat, shocks, humidity or chemicals.

Long battery life

Providing on average 360 hours of use and easily changed without the need for tools.

Wireless operation

The transmitter unit wirelessly transfers data to the facemask, avoiding time consuming connection of cables, reducing costs and connection errors.

Easy to read LEDs

Red, amber and green LEDs provide precise information about your cylinders air pressure at all times. The display automatically adapts to ambient brightness enabling clear indication of pressure information , even under poor lighting conditions.

Additional low-air pressure warning

In addition to the SCBA's primary low-pressure alarm whistle, a red LED on the HUD flashes if the cylinder pressure reaches the low-pressure warning threshold. This provides the wearer with an additional warning.

System Components



D-7756-2019

Dräger FPS® 7000

The Dräger FPS® 7000 full-face mask sets the standard in safety, visibility, and comfort. Triple-sealing, the FPS 7000 comes in nine sizes and three shapes of the inner mask to ensure maximum protection by adapting to different head and face shapes.

Technical Data

Dräger Sentinel 7000

Approvals

NFPA 1981 & 1982, 2018 Edition

Not all products, features, or services are for sale in all countries.
Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to www.draeger.com/trademarks to find the current status.

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

USA

Draeger, Inc.
7256 S. Sam Houston Parkway W.,
Suite 100
Houston, TX 77085
1 800 4DRAGER
(1 800 437 2437)

CANADA

Draeger Safety Canada, Ltd.
2425 Skymark Ave., Unit 1
Mississauga, Ontario L4W 4Y6
1 877 DRAGER1
(1 877 372 4371)

Locate your Regional
Sales Representative at:
www.draeger.com/contact

