

## Technical Specification

### Dräger Wash6DR Barrier

Automatic cleaning machine

Made by

**Harstra**  
INSTRUMENTS

- double door cover for separating dirty and clean rooms and positioning between two rooms in the wall prevents cross-contamination
- On one side, the dirty products are loaded into the dirty room; the cleaned products are removed from the cleaning machine via the other side into the clean room
- During washing, the door flaps are electrically locked, after the cleaning process only released on the clean side
- Respirators are cleaned without cylinder
- Special pipe ensures that the products remain under pressure during the cleaning process so that no moisture can get into the device (air pressure of 90 bar)
- The water temperature in the washing tank is 55 °C
- Connection diameter drain pipe: 50 mm
- 4 pieces stainless steel wire baskets or 2 pieces mounting frames for breathing air masks optionally installable



Wash6DR Barrier  
(Fig. similar)



water softening system  
(Fig. similar)

## TECHNICAL DATA

Dimensions (H x W x D)	Exterior 1800 x 1290 x 850 mm
Outside with open door cover	2170 x 1290 x 2150 mm
Washroom 2x	300 x 975 x 620 mm
Tank capacity	90 l
max. capacity	6x SCBA without cylinder
Main link	400 Volt, 3-Ph. 50 Hz.
Breathing air connection	High pressure incl. 6x flexible hoses, connection G 5/8" and one valve
Washing times	5 minutes   10 minutes   22 minutes

## ORDER INFORMATION

Dräger Wash6DR Barrier

69 26 693

## ACCESSORIES

Water Softening System (WO)



### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53-55  
23558 Lübeck, Germany

[www.draeger.com](http://www.draeger.com)

### Manufacturer

Lenhardt & Wagner GmbH  
An der Tuchbleiche 39  
68623 Hüttenfeld, Germany

### REGION DACH

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck  
Tel +49 451 882 0  
Fax +49 451 882 2080  
[info@draeger.com](mailto:info@draeger.com)

### REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA  
Branch Office  
P.O. Box 505108  
Dubai, United Arab Emirates  
Tel +971 4 4294 600  
Fax +971 4 4294 699  
[contactuae@draeger.com](mailto:contactuae@draeger.com)

### REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.  
Complejo Business Park  
V tower, 10th floor  
Tel +507 377 9100  
Fax + 507 377 9130  
[contactcsa@draeger.com](mailto:contactcsa@draeger.com)

### REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd  
25 International Business Park  
#04-20/21 German Centre  
Singapore 609916  
Tel +65 6308 9400  
Fax +65 6308 9401  
[asia.pacific@draeger.com](mailto:asia.pacific@draeger.com)