

## Technical Specification

### Dräger Wash6DR

Automatic cleaning machine



Made by

**Harstra**  
INSTRUMENTS

- The SCBA's without cylinder will be cleaned on two separate levels, by means of several nozzles. combined with the cleaning agent Dräger recommends
- The Wash6DR is supplied by Dräger with a fixed high pressure tube (breathing air) to prevent moisture from entering the pneumatics.
- Components of the washing compartment include:
  - a centrifugal pump for the main wash
  - a level switch as dry running safety and low water control system
  - an overflow in the tank
  - a washing water tank, contents approx. 90 litres and a post rinse tank of approx. 20 litres
  - a discharge pump, to drain the tank
  - a removable sieve
  - a moving washing frame, with bayonet jets for the main wash



Cleaning machine Wash 6DR  
(Fig. similar)



external high pressure connection with blind plug  
(Fig. similar)



external high pressure connection  
(Fig. similar)



connected breathing apparatus  
(Fig. similar)

## TECHNICAL DATA

Dimensions (H x W x D)	Exterior 1800 x 1335 x 850 mm
Outside with open door cover	2410 x 1335 x 850 mm
Washroom	2x 300 x 975 x 630 mm
Tank capacity	90 l
max. capacity	6x SCBA without cylinder
Main link	400 Volt, 3-Ph. 50 Hz.
Breathing air connection	High pressure incl. 6x flexible hoses, connection G 5/8" and one valve
Washing times	5 minutes   10 minutes   22 minutes

## ORDER INFORMATION

Wash 6DR (W6DR)

69 26 692

## ACCESSORIES

Water Softening System (WO)

### CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53-55  
23558 Lübeck, Germany  
[www.draeger.com](http://www.draeger.com)

#### Manufacturer

Harstra Instruments B.V.  
Giek 11 | 3891 KA Zeewolde |  
Nederland  
Postbus 186 | 3890 AD Zeewolde |  
Nederland

#### REGION DACH

Dräger Safety AG & Co. KGaA  
Revalstraße 1  
23560 Lübeck  
Tel +49 451 882 0  
Fax +49 451 882 2080  
[info@draeger.com](mailto:info@draeger.com)

#### REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA  
Branch Office  
P.O. Box 505108  
Dubai, United Arab Emirates  
Tel +971 4 4294 600  
Fax +971 4 4294 699  
[contactuae@draeger.com](mailto:contactuae@draeger.com)

#### REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.  
Complejo Business Park  
V tower, 10th floor  
Tel +507 377 9100  
Fax + 507 377 9130  
[contactcsa@draeger.com](mailto:contactcsa@draeger.com)

#### REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd  
25 International Business Park  
#04-20/21 German Centre  
Singapore 609916  
Tel +65 6308 9400  
Fax +65 6308 9401  
[asia.pacific@draeger.com](mailto:asia.pacific@draeger.com)