

Dräger DiveSorb® Pro Rebreather Diving Equipment

Dräger DiveSorb® Pro was developed specifically for closed or semi-closed rebreathers in order to allow a high degree of CO₂ absorption, and thus long dive times.



Benefits

Absorption of carbon dioxide in professional diving apparatus

DiveSorb Pro is a high-performance sodalime, which absorbs the carbon dioxide contained in exhaled air. The proven Dräger-Quality allows a reproducible absorption behavior.

Unique pill shape through hemisphere

The hemispherical shape of the absorbent ensures low breathing resistance and efficient usage.

Optimally aligned absorbent for diving apparatus

The absorbent is perfectly aligned for modern diving apparatus and is suitable for demanding usage. DiveSorb Pro is highly resistant to abrasion, therefore levels of dust formation are very low. The low amount of dusts protects the device and the operator.

Technical Data

Composition	calcium hydroxide, alkali hydroxide, water		
Shape	hemispherical pellet		
Grain size	Ø approx. 4 mm	ISO 3310, 2 to 4 mm	ASTM E11, 5 to 10 No
Water content	(16 +/- 2) %		
Density	875 +/- 125 g/L		
CO ₂ absorption capacity	depending on the operation parameters and the absorption system		
Storage temperature	-30 °C to +50 °C		
Shelf life after production	5 years		
Indicator	no color indicator		

Canister dimensions

Weight	L x W x H rounded
4.8 kg	195 x 170 x 260
18 kg	290 x 270 x 450

Ordering Information

		Nato stock no. (NSN)	Dräger Order no.
Dräger DiveSorb® Pro	4,8 kg soda lime (canister)	4240-12-348-4361	67 37 062
Dräger DiveSorb® Pro	16,8 kg soda lime (canister)		67 37 818
Dräger DiveSorb® Pro	18 kg soda lime (canister)	4240-12-376-0682	67 37 109

Notes

Not all products, features, or services are for sale in all countries.
Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to www.draeger.com/trademarks to find the current status.

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

REGION EUROPE

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
Tel +49 451 882 0
Fax +49 451 882 2080
info@draeger.com

REGION MIDDLE EAST, AFRICA

Drägerwerk AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

REGION ASIA PACIFIC

Draeger Singapore Pte. Ltd.
61 Science Park Road
The Galen #04-01
Singapore 117525
Tel: +65 6872 9288
Fax: +65 6259 0398
asia.pacific@draeger.com

REGION CENTRAL AND SOUTH AMERICA

Dräger Indústria e Comércio Ltda.
Al. Pucurui - 51 - Tamboré
06460-100 - Barueri - São Paulo
Tel. +55 (11) 4689-4900
relacionamento@draeger.com

CANADA

Draeger Medical Canada Inc.
2425 Skymark Avenue, Unit 1
Mississauga, Ontario, L4W 4Y6
Tel +1 905 212 6600
Toll-free +1 866 343 2273
Fax +1 905 212 6601
Canada.support@draeger.com

Locate your Regional Sales
Representative at:
www.draeger.com/contact

