

## Dräger Mine Rescue Support Trailer

The Dräger Mine Rescue Support Trailer is a mobile, fully self-supporting work center designed to conduct full maintenance and repair of our PSS® BG4 plus closed-circuit breathing apparatus and related equipment.



## Benefits

---

### Multi-functional Workshop

The Dräger Mine Rescue Support Trailer is equipped with a number of devices and features that facilitate maintenance and repair of the Dräger PSS® BG 4 plus closed-circuit breathing apparatus and related components. It has been designed to be a fully self-supported facility, designed for operation at any location.

## System Components



### Dräger RZ 7000 Tester

With the Dräger RZ 7000 you can carry out the function and leak tests of the Dräger PSS® BG 4 plus easier and faster than ever before.



### Dräger DOB 200 ECO Oxygen Booster Pump

The counter top-mounted Dräger DOB 200 ECO is a compact oxygen booster pump that allows you to fill up to four Dräger PSS® BG 4 plus cylinders simultaneously, in just a few minutes. This space-saving device is also portable and can be transported to another location, if needed.

## System Components

ST-9219-2007



### Dräger DM-6 Mask Dryer

The Dräger DM-6 Mask Dryer has been specifically designed for use with Dräger's BG 4 closed-circuit breathing apparatus. The DM-6 can quickly dry components from up to six BG 4 units at one time.

D-15559-2017



### Ample Storage

The Dräger Mine Rescue Support Trailer provides ample storage, with multiple secure cabinets, two shelving units, and secure cylinder storage. In addition, a full tool crib has been built into the counter space. The overall area of counter space offers 35 sq/ft (3.3 sq/m) of work space and there are 22 AC power outlets spanning this area.

D-15560-2017



### Washing Area

The Dräger Mine Rescue Support Trailer is equipped with a full washing area, including a sink and ample counter space, as well as an on-board hot water heater and a high gallon reserve tank. The tank is easily refillable via an external hose line.

D-15561-2017



### Fully Climatized

The unit is fully air conditioned, with an efficient, adjustable climate control unit for cooling or heating the entire work area from a central location.

## System Components



D-15562-2017

---

### Ease of Operation

Powered by a 10.8 hp (8 kW) diesel generator, the unit is powered up at the press of a button. To facilitate activation without ambient lighting, 12v service lights, connected to vehicle power, offer adequate lighting for this activity. The unit also powers off at the touch of a button.



D-15563-2017

---

### Mobile Unit

The Dräger Mine Rescue Support Trailer is designed within a heavy duty cargo trailer with a standard tow hitch and 12 volt power connections. All of the Dräger-installed components are installed for on-road transit and are DOT compliant.

## Technical Data

### Additional features

- 
- Two shelving units with over 24 sq/ft (2.2 sq/m) of open storage
  - Multiple general-purpose cabinets
  - 35 sq/ft (3.3 sq/m) of counter space to assist in maintenance, washing and repair
  - Secure storage for 12 oxygen cylinders
  - Full height clothing closet with 20 inches (.5 meters) of lateral hanger space
  - External water drain line with shut-off valve
  - Full length exterior retractable awning
  - Exterior power outlet (2)
- 

### Technical data

Weight (including components)	7830 lbs (3550 kg)
Dimensions (L x W x H, including tow hitch)	287" x 108" x 128" (7290 mm x 2743 mm x 3250 mm)
Power supply	120V / 60Hz
Generator power	10.8 HP (8 kW)
Generator power source	Diesel

## Notes

Not all products, features, or services are for sale in all countries.  
Mentioned Trademarks are only registered in certain countries and not necessarily in the country in which this material is released. Go to [www.draeger.com/trademarks](http://www.draeger.com/trademarks) to find the current status.

### **CORPORATE HEADQUARTERS**

Drägerwerk AG & Co. KGaA  
Moislinger Allee 53–55  
23558 Lübeck, Germany  
[www.draeger.com](http://www.draeger.com)

### **USA**

Draeger, Inc.  
7256 S. Sam Houston Parkway W.,  
Suite 100  
Houston, TX 77085  
1 800 4DRAGER  
(1 800 437 2437)

### **CANADA**

Draeger Safety Canada, Ltd.  
2425 Skymark Ave., Unit 1  
Mississauga, Ontario L4W 4Y6  
1 877 DRAGER1  
(1 877 372 4371)

Locate your Regional  
Sales Representative at:  
[www.draeger.com/contact](http://www.draeger.com/contact)

