

Sekusept® Cleaner Liquid Cleaning Agent Cleaning, Disinfecting and Drying

Concentrated liquid cleaning agent for manual cleaning of respiratory masks, respiratory protection equipment, diving apparatus and chemical protective suits before disinfection.



D-98827-2013

Benefits

Product

Sekusept Cleaner is a cleaning agent for manual cleaning with cloth and sponge before disinfection in an immersion bath. For cleaning chemical protection suits, a brush can also be used.

Advantages

- Exceptional cleaning power
 - Exceptional material compatibility
 - User-friendly formula
 - Efficient because of low usage concentration
-

Application instructions

Strictly observe the respective Dräger Instructions for Use for respiratory masks, respiratory protection equipment, chemical protective suits etc. as well as the application instructions of the product manufacturer!

Related Products



D-98825-2013

Incidin® Rapid Disinfectant

Liquid disinfectant concentrate for disinfection of respiratory masks, respiratory protection equipment, diving apparatus, chemical protective suits, drying cabinets, work surfaces and floors.

Related Products



D-4073-2014

Cleaning working clothing

Work clothing is often exposed to extreme conditions. To be ready and well prepared for the next use, the clothes have to be cleaned and disinfected using the right agents.



D-3957-2014

Cleaning of test devices and surfaces

Hygienic and clean: Special cleaning agents and disinfectants for all kinds of surfaces ensure sterile working environments.



ST-7476-2008

Personal hygiene

Tough against bacteria – but soft on your skin. The gentle cleaning, disinfecting and care products protect the skin even if used frequently.

Technical Data

DOSAGE

	Efficiency (%)	Concentration (ml/L)
Cleaning of respiratory protection devices and respiratory protection equipment in an immersion bath	0,5 – 1	5 – 10

DOSING TABLE – LIQUID

Litre(s)	Concentration for use ¹⁾	
	0,5%	1%
1 litre	5 ml	10 ml
2 litres	10 ml	20 ml
3 litres	15 ml	30 ml
4 litres	20 ml	40 ml
5 litres	25 ml	50 ml
8 litres	40 ml	80 ml
10 litres	50 ml	100 ml
20 litres	100 ml	200 ml
30 litres	150 ml	300 ml

¹⁾ Observe concentration given in the respective Instructions for Use

Application instructions:

Example: 10 litres = 1 % application solution = 100 ml of concentrated product + 9.9 litres of water.

Add concentrated product according to the water volume, stir briefly.

Solution can be used immediately. For normal contamination the solution can be used for one working day.

If the solution is visibly contaminated, please prepare new cleaning solution.

Ordering Information

Sekusept® Cleaner	1 x 2 L bottle with measuring cup	R 62 805
Sekusept® Cleaner	4 x 2 L bottle with measuring cup	R 62 063

Separate product information can be requested from ECOLAB for usage as cleaning agent for medical products.

Manufacturer: Sekusept® is a registered trademark of ECOLAB.

Notes

Notes

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

Manufacturer:

Ecolab Deutschland GmbH
Ecolab-Allee 1
40789 Monheim am Rhein
Germany
Tel +49 (0) 2173-599-0

Locate your Regional
Sales Representative at:
www.draeger.com/contact

