

Dräger workshop accessories Workshop Furniture

Dräger offers a large selection of accessories. Each product helps make the required work even easier.



ST-2247-2006

Benefits

Compressed air distributor

The Dräger compressed air distributor is used to clean and disinfect the lung demand valve under pressure. Its stainless steel housing features seven rotating couplings for respiratory equipment to connect a maximum of seven lung demand valves via the medium pressure hose - additional couplings are available upon request. Due to the constant pressure no water can enter the equipment during cleaning.

Metering devices

The DG1 is a stationary metering device for disinfectants. This admixture device for disinfectant offers protection against the backflow of disinfectant into the drinking water mains network. It offers a precise automatic metering of the disinfectant to be added in proportion to the water volume flowing thru it. The required quantities can be adjusted. For personal hygiene a triple wall dispenser for Manisoft®, Skinman® soft and Silonda® Lipid is provided.

Transport trolley

The transport trolley serves the transportation of respiratory equipment. The trolley is supplied with three level floor plates. The base is equipped with four steering rollers, two of which are adjustable. Upon request the trolley is also available with a plastic tray to transport chemical protection suits or batch deliveries.

Protection and storage bags

For the ideal storage and transportation of the protective equipment there exists a multitude of cleaning, storage and transport sleeves, for example the wash and storage bags for respiratory masks and compressed air breathing apparatus. For chemical protection suits we offer a storage and transport sleeve as well as a visor protection hood for machine cleaning.

Pneumatic clamping device

For the safe clamping of respiratory equipment cylinders from steel and composite materials there is the pneumatic clamping device. It secures breathing air cylinders with a diameter between 80 and 220 millimeters with the specified torque whilst the cylinder valves are screwed in or out. The cylinders are easily held in place via rack rails – no additional tools are required. The clamping pressure is indicated on a manometer. To assure every operator that the setting is correct, the clamping forces for steel and composite cylinders have been preset.

Cylinder trolley

The cylinder trolley is made from chrome nickel steel and provides safe transportation of compressed air cylinders. Its reinforced base and two spacing screens allow for the optimum positioning of the cylinders. With its four steering rollers – two of which are adjustable – it moves with great ease. Dependent on equipment, the cylinder trolley can be loaded with 12 to 24 compressed air cylinders.

Benefits

Drip device

With the drip device masks and other rebreather components can be suspended above the rinsing cabinet system. It consists of four rails with five hooks each and can be wall-mounted. Upon request the device is supplied with retaining clips to suspend the devices from the filter connection. Chemical protection suits can be dried on wall holders. The chemical protection suits can also be dried by a fan in a short period of time using a special frame.

Notes

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53–55
23558 Lübeck, Germany
www.draeger.com

Manufacturer:

Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany

REGION EUROPE CENTRAL AND EUROPE NORTH

Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany
Tel +49 451 882 0
Fax +49 451 882 2080
info@draeger.com

REGION EUROPE SOUTH

Dräger Safety France SAS
25, rue Georges Besse
92182 Antony Cedex
Tel +33 1 46 11 56 00
Fax +33 1 40 96 97 20
europa.south@draeger.com

REGION MIDDLE EAST, AFRICA

Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd
25 International Business Park
#04-20/21 German Centre
Singapore 609916
Tel +65 6308 9400
Fax +65 6308 9401
asia.pacific@draeger.com

REGION CENTRAL AND SOUTH AMERICA

Dräger Panama S. de R.L.
Complejo Business Park,
V tower, 10th floor
Panama City
Tel +507 377 9100
Fax +507 377 9130
contactcsa@draeger.com

Locate your Regional
Sales Representative at:
www.draeger.com/contact

