

Dräger X-plore® 4700 Half Masks

The Dräger X-plore® 4700 is the robust half mask which offers excellent comfort and outstanding leak tightness for demanding applications. Thanks to the wide range of filters available for protection against gases, vapours and particles, it is ideally suited for use in a variety of industries.



The combination of soft mask body, specially shaped nose seal and a sturdy plastic frame offers key advantages during long term use: a perfect fit on different face shapes and sizes, superior leak tightness, and virtually no pressure points. The ergonomic FlexiFit head harness makes the mask easy to don and doff without hair entanglement or unnecessary pressure. The mask can be removed simply by releasing the neck hook, without taking off the safety helmet ("drop down" strap system). The exhalation valve is positioned low and reliably removes moisture, maintaining a dry and pleasant atmosphere inside the mask.

Two high quality materials are available to choose from: TPE or extremely comfortable silicone, especially good for sensitive skin.

The silicone version is also available in two sizes. Two different connectors can be ordered, either for use with Dräger X-plore Rd40 filters (as per EN 148-1), or Dräger X-plore Rd90 filters (Dräger-specific). A wide range of gas, particle and combination filters are available for both connectors.

Benefits:

- Outstanding comfort
- Excellent fit
- Virtually no pressure points
- Choose between two different sizes and filter connectors
- Wide range of filters



ST-7496-2005

Dräger X-plore® 4740
TPE



ST-700-2006

Dräger X-plore® 4790
Silicone



ST-12765-2007

Dräger X-plore® 4790
Silicone, EH**

TECHNICAL DATA

Mask body	Silicone (black) or TPE (grey-transparent) Additionally, blue hard body made of durable PP plastic
Sizes	Silicone: small/medium (S/M) and medium/large (M/L) TPE: universal size
Filter connector	Standard thread connection Rd40 (RA) as per EN 148-1 (Dräger X-plore® 4740) Dräger-specific thread connection Rd90 (Dräger X-plore® 4790)
Weight	Dräger X-plore® 4740: 160 g respectively 175 g Dräger X-plore® 4790: 180 g respectively 195 g
Head harness	Flexible and robust neoprene strap (CR/NR), two adjustment points, FlexiFit TPE head harness, drop-down option EH-version: elastic harness made of sturdy, chemical resistant neoprene
Approvals	CE certified (EN 140), AS/NZS
Spare parts	Available

ORDER INFORMATION

Mask	Size	Order no.
Dräger X-plore® 4740, Silicone	medium/large (M/L)	R 55 874
	small/medium (S/M)	R 55 875
Dräger X-plore® 4740, Silicone, EH**	medium/large (M/L)	R 56 710
Dräger X-plore® 4740, TPE	universal size	R 55 876

The Dräger X-plore® Rd40 filter series is compatible with the Dräger X-plore® 4740 half masks. The Rd40 filters have a standard thread connection as per EN 148-1 and include an extensive range of different particle, gas and combination filters (see separate data sheet Dräger X-plore® Rd40 Filters for further details).

Mask	Size	Order no.
Dräger X-plore® 4790, Silicone	medium/large (M/L)	R 55 877
	small/medium (S/M)	R 55 878
Dräger X-plore® 4790, Silicone, EH**	medium/large (M/L)	R 56 715
	small/medium (S/M)	R 56 720
Dräger X-plore® 4790, TPE	universal size	R 55 879

The Dräger X-plore® Rd90 filter series (with Dräger-specific connector) is compatible with the Dräger X-plore® 4790 series. The Dräger Rd90 filters include a comprehensive range of different particle, gas and combination filters (see separate data sheet Dräger X-plore® Rd90 Filters for further details).

**EH: Elastic harness

CORPORATE HEADQUARTERS

Drägerwerk AG & Co. KGaA
Moislinger Allee 53-55
23558 Lübeck, Germany

www.draeger.com

AUSTRALIA

Draeger Safety Pacific Pty. Ltd.
Axxess Corporate Park
Unit 99, 45 Gilby Road
Mt. Waverley Vic 3149
Tel +61 3 92 65 50 00
Fax +61 3 92 65 50 95

P. R. CHINA

Draeger Safety Equipment
(China) Co., Ltd.
A22 Yu An Rd, B Area,
Tianzhu Airport Industrial Zone,
Shunyi District, Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

FRANCE

Draeger Safety France SAS
3c route de la Fédération,
BP 80141
67025 Strasbourg Cedex 1
Tel +33 3 88 40 76 76
Fax +33 3 88 40 76 67

NETHERLANDS

Dräger Safety Nederland B.V.
Edisonstraat 53
2700 AH Zoetermeer
Tel +31 79 344 46 66
Fax +31 79 344 47 08

REGION ASIA PACIFIC

Draeger Safety Asia Pte Ltd
67 Ayer Rajah Crescent
#06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

REGION CENTRAL

AND SOUTH AMERICA
Dräger Panama S. de R.L.
Complejo Business Park,
V tower, 10th floor
Panama City
Tel +507 377-9100
Fax +507 377-9130
contactcsa@draeger.com

REGION MIDDLE EAST,

AFRICA
Dräger Safety AG & Co. KGaA
Branch Office
P.O. Box 505108
Dubai, United Arab Emirates
Tel +971 4 4294 600
Fax +971 4 4294 699
contactuae@draeger.com

SPAIN

Dräger Safety Hispania S.A.
Calle Xaudaró 5
28034 Madrid
Tel +34 91 728 34 00
Fax +34 91 729 48 99

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside
Business Park
Blyth, Northumberland
NE24 4RG
Tel +44 1670 352-891
Fax +44 1670 356-266

Manufacturer:

Dräger Safety AG & Co. KGaA
Revalstraße 1
23560 Lübeck, Germany